



## POND SIDE

NOTE: ALL JETS ARE TO BE INSTALLED 12" BELOW THE WATER LINE

NOTE: PONDS WITH 5 OR LESS JETS YOU CAN USE 1 1/2" PVC RATHER THAN 2" PVC TO RUN JET LINES

2 JET LINE  
1" = 1'-0" CONCRETE PONDS ONLY